# **REMOTE ALARM**



# For climate monitoring in up to 20 compartments

When developing the remote alarm, we attached great importance to achieving a simple user interface without compromising the setting options. The remote alarm features a touch screen making the remote alarm a safe and logical tool at all times.

#### Features

- The Remote alarm computer can monitor 1 to 20 compartments (analogue inputs).
- The Remote Alarm is based on state-of-the-art technology and an advanced operating system and is therefore easy to update and expand with more functions and capacity.
- The flexible composition of the hardware in the Remote Alarm makes it possible to choose the sensor which is exactly optimal for a particular production.
- It is also possible to use more than one of each sensor in each room.
- This flexibility provides a high degree of accuracy and safety.
- The remote alarm can be connected to SuperLink 5 & 6 via Ethernet.

#### In general

- The Remote Alarm can be used to monitoring the climate in your houses and to send out an alarm if e.g. the temperature is not within your specified range.
- The Remote alarm consists of the basic software and the operation panel.
- It is possible to connect the following Senmatic sensors to the Remote alarm:
  - ✓ Air temperature sensor
  - ✓ Flow temperature sensor
  - ✓ Humidity sensor
- Depending on which Remote Alarm you have, it will have between 8-20 analogue inputs.
- Each of the analogue inputs can be set freely to match the 3 sensor types.
- The 6 digital inputs can be used for detection of other alarms.
- As default, a high level on a digital input means alarm, but it's possible to invert this by means of a setting.





# SPECIFICATIONS / REMOTE ALARM

## **Technical specifications**

Supply Voltage:	100 - 240 V AC - 50/60 Hz
Communication:	Ethernet

# **Physical specifications**

Temperature, operation:	0 - 50°C (32 - 122°F) No direct sun radiation
Humidity:	0 - 95 % RH Without condensation
Density:	IP65
Dimensions L x W x H:	350 x 250 x 130 mm
Weight:	Approx. 6.5 kg (14 lb)

### Variants:

#### Remote Alarm 8 Comp. I/O's

- Digital inputs 6
- Digital outputs 2 8
- Analogue inputs

# Remote Alarm 12 Comp. I/O's

- Digital inputs
- Digital outputs
- Analogue inputs 12

#### Remote Alarm 16 Comp. I/O's

- Digital inputs 6
- Digital outputs 2
- Analogue inputs 16

# Remote Alarm 20 Comp. I/O's

- Digital inputs
- Digital outputs
- Analogue inputs 20

The two digital outputs are used for two types of alarm indication. One for high priority and one for low priority alarms. You can define the active periods for each type of alarm.

6

2

6 2

Distributor:

Contact details: DGT by Senmatic Phone: +45 64 89 22 11 dgtsales@senmatic.com – www.senmatic.dk